

#7200 TRUCK FRONT SUSPENSION KIT

Follow these instructions to assemble your front suspension kit.

- 1 Push the #6220 axle into the #6221 steering block.
- 2 Add the #6221 steering block to the #6210 block carrier with the #6223 kingpin and #6299 E-clips.
- 3 Add your #6951 set screw to the end of the #6220 axle and tighten it.
- 4 Carefully separate the #7206 suspension arms from the parts tree.
- 5 Attach the #6210 block carrier to the #7206 suspension arms with the #6227 hinge pins and #6299 E-clips.
- 6 Attach the #7206 suspension arms and #7208 aluminum support to the #7207 front bulkhead with the #7209 hinge pin and #6299 E-clips.

- 7 Attach the #7215 front shock tower to the #7207 front bulkhead with the two #6925 screws.
- 8 Mount the #7207 front bulkhead to the chassis with the four #6280 screws.
- 9 Add the #6936 washers to the #6221 steering block, then screw the #6273 ball end on.
- 10 Screw the #6273 ball end onto the #6210 block carrier and add a #7260 nut to the end.
- 11 Screw the #6274 ball cups onto the ends of the #7253 turnbuckle
- 12 Pop the #7253 turnbuckle ball cup onto the ball end that is on the #6210 block carrier.
- 13 Use the #6222 lock nut to hold the wheel to the front axle.

Follow the instructions in your manual to complete the installation.

